

Standheizung freischalten bei 4 Zonen Klima

Beitrag von „TAltemeier“ vom 24. Januar 2012 um 16:01

[Zitat von tthom](#)

From factory this heater is used only after engine start, but its easy to make it work as a parking heater and activate timers menu in RNS.

1 In Hidden menu check option car/cardevicelist - Auxiliary Heater

2 set option Auxiliary Heater to 5 in car / carmenuoperation

3 set enabled bit 4 in byte 1 of 08-AutoHVAC module.

Then turn off the ignition and start once again. A menu Aux Heater should appear in Climate screen of RNS. There you could setup a day, time and duration of heating. at fixed time you should see ventilation start, and even some smoke under the car

Alles anzeigen

Sollte nach den Änderungen der Button "Standheizung" nicht sichtbar sein, hilft ein Neustart des Computers. Entweder Fahrzeug abstellen und warten - irgendwann fährt der ja von selbst herunter oder alternativ

über **Phone-Climate-Nav-Traffic-Knopf in der Mitte** neustarten.

Je nachdem ob bei dem Fahrzeug eine Frontscheibenheizung eingebaut ist oder nicht, erscheint der Knopf für die "Standh." in der Mitte oder ganz Rechts.