

Touareg Dead Pedals

Beitrag von „dschlei“ vom 12. März 2005 um 18:12

Zitat von Thomas TDI

Danke!

Thomas

Hier ist ein Arbeitsablauf von Spockcat für die Pedals (in Anbetracht des Aufwands und der Geräte die man haben muss, habe ich gerade eins bei Spockcat bestellt!):

How the dead pedal is made:

- 1) using a VW Beetle Turbo S dead pedal (VW P/N: 1C1 864 777), unpack and strip off backing plate, middle rubber piece and plastic protection cover. Set aside rubber piece and discard other pieces.
- 2) using template, trace outline on face of dead pedal metal piece.
- 3) cut dead pedal using plasma cutter.
- 4) use template on back of pedal for notcher cuts.
- 5) Use notcher in to make ~20 cuts according to template.
- 6) grind all cut edges.
- 7) bend inner lip of pedal so it will accept the new backing plate.
- 🤪 make 4 new bends in pedal using large and small brakes.
- 9) cut rubber material from step 1 to fit pedal.
- 10) cut new sheet metal backing plates and apply into pedals.
- 11) bend, fit, trim and lock new backing plate onto pedal.
- 12) test fit in Touareg and bubble wrap for stock/shipment.