

Rückspiegel Blinker ersetzen

Beitrag von „cashburner“ vom 4. Juli 2007 um 13:50

Hi Christian/Salvatore,

Also:

nach folgender perfekter Anleitung läßt sich ein Blinkereinsatz austauschen.

Das aufgeführte Spezialwerkzeug 80-200 ist unnötig - man kann einen Blechstreifen passend biegen und mit Klebeband die Kante schützen.

Als Kurzanleitung kann ich mitteilen:

Spiegelglas vorsichtig heraushebeln, Steckkontakte abziehen, u.g. Schrauben entfernen und Spiegelgehäuse mit etwas fummeln abnehmen, Schrauben der Blinkerhalterung lösen und Blinker ersetzen, Steckkontakte nicht vergessen.

Auf diese Weise kann auch die Türeinstiegsleuchte ersetzt werden.

Diese Anleitung ist für den Fahrerspiegel, die Beifahrerseite geht genau seitenverkehrt.

Gruß Cashburner

Removing Mirror Glass:

- Protect edge of housing - 1 - from damage to paintwork e.g. with fabric-reinforced adhesive tape.
- Press bottom of mirror glass into mirror housing.
- Press off - arrow 5 - mirror glass - 3 - from retainer - 2 - , using pry lever 80-200.
- Fold mirror glass upward - arrow 6 - and disconnect connector - 4 - for mirror heater on back of mirror glass.

(Anhang Bild Spiegel1)

Removing Mirror housing, removing and installing

- Remove mirror glass (see post above)
- Fold rearview mirror toward front for easier assembly.
- Remove four bolts - 1 - .
- Loosen bolt - 3 - and remove with cap - 2 - .
- Pull off mirror housing - 5 - upward from mirror base plate - 4 - .

(Anhang Bild Spiegel2)