

Memory Seats and Remote Key

Beitrag von „IT-CS“ vom 22. März 2005 um 09:31

Hi,

you must store the seat position by pressing set and memory 1 (example), pull out the key and press the door-open button on the key for more than 10 sek.; a ping will be heard. Now it will work. The seat goes in the stored position when you open the door. In my Touareg it will work fine.

greeting, Jörg